



INSTRUCTION MANUAL APN AND BASIC NETWORK CONFIGURATION Apple iPhone SE 2020

STEP 1: **Insert Geoverse SIM Card**

This follows the standard process as inserting any other SIM card. Insert the card and skip to step 2 or follow the instructions below to learn how.



Remove/Pop out the SIM from the larger card. Insert the SIM removal pin that came with your phone into the hole in the small tray on the right side of your phone. You may have to apply some pressure to open it. Place the SIM Card into the tray and close it. If the phone is off, turn it on, otherwise, reset it.




Step 2: Configure Settings


You can verify that your device is on the 'Geoverse' network from your home screen.

To change this, navigate to your settings menu. Select the options for Cellular, then Network Selection, and then 'Geoverse.'


If you wish to choose a network automatically, you may toggle the switch to 'automatic mode.'



You have the option to turn on 'Roaming' by selecting Cellular Data Options.




Make sure that under Voice and Data, LTE and VoLTE is On.



Step 3: Configure APN

Under the Settings menu, navigate to Cellular Data Network then to Set your APN



Make sure to save the APN configuration settings.

If this does not work, please power cycle your device.